


Telescopics Specifications

Dimensions



- (R*) External turning radius with 24" tyres (with forks spaced 1040 mm ext.)
- (G) Carriage rotation angle

B3G4 11001 - B3G4 99999 •


136.0°



Telescopics Specifications

TL26-60/TL30-60 100 Low Cab IIIA R-Series Telescopic Handler

Load Charts




B3G4 11001 — B3G4 99999 • Specifications are subject to change without notice - Pictures of Bobcat units may show other than standard equipment



Telescopics Specifications

Load Charts





Telescopics Specifications

Performance

Tenomance	
Tilt Breakout force	4600 daN
Drawbar pull (20" tyres)	4900 daN
Drawbar pull (24" tyres)	4100 daN
Max. gradeability (20" tyres)	24.0°
Max. gradeability (24" tyres)	24.0°
Max. gradeability with rated load (20" tyres)	24.0°
Max. gradeability with rated load (24" tyres)	24.0°
Rated capacity	3000 kg
Capacity (at max. height on tyres)	2500 kg
Capacity at max. reach (20" tyres)	1250 kg
Capacity at max. reach (24" tyres)	1300 kg
Lifting height (20" tyres)	5800.0 mm
Lifting height (24" tyres)	5890.0 mm
Max. reach (20" tyres)	3100.0 mm
Max. reach (24" tyres)	3010.0 mm
Reach at max height on tyres (20" tyres)	420.0 mm
Reach at max height on tyres (24" tyres)	330.0 mm
Cycle times	
Boom raising	5.3 s
Boom lowering	4.0 s
Boom extension	5.0 s
Boom retraction	3.6 s
Crowding	2.5 s
Dumping	2.4 s
Weights	
Unladen weight (20" tyres)	5020 kg
Unladen operating Weight (20" tyres)	5180 kg
Unlade operating Weight on front axle (20" tyres)	2340 kg
Unladen operating Weight on rear axle (20" tyres)	2840 kg
Unladen weight (24" tyres)	5140 kg
Unladen operating Weight (24" tyres)	5300 kg
Unlade operating Weight on front axle (24" tyres)	2400 kg
Unladen operating Weight on rear axle (24" tyres)	2900 kg
Max ground Pressure on tyres-hard soil	11.0
Engine	
Make / Model	PERKINS / 1104D-44TA
Fuel	DIESEL
Cooling	WATER
Rated power (ISO 14396)	74.0 kW
Rated power (ISO 14390) Rated speed	2200.0 RPM
•	410.0 Nm
Maximum torque at 1400 rpm	
Number of cylinders	4.0
Displacement	4.40 L
Bore	105.0 mm
Stroke	127.0 mm
Lubrication	Gear pump pressure
B3G4 11	1001 — B3G4 99999 •

B3G4 11001 — B3G4 99999 • Specifications are subject to change without notice - Pictures of Bobcat units may show other than standard equipment



Telescopics Specifications

Crankshaft Ventilation Air filter Ignition	Open breathing Dry replaceable cartridge with safety element Diesel compression
Electrical	
Alternator Battery Starter	90 A 110.0 3.2 kW
Hydraulic System	
Pump type Pump capacity Relief valve pressure setting Control valve type Hydraulic filter specs Auxiliary flow front Auxiliary flow rear	Gear pump with LS valve 100.00 L/min 250.00 bar Open center with flow sharing & flow compensators technology Full flow filtration 90.00 L/min 20.00 L/min
Drive system	
Transmission Main Drive	Hydrostatic with electronic regulation Hydrostatic motor
Traction	
Standard Tyres Max speed - turtle mode (24" / 20") Max speed - rabbit mode (24" / 20") Max speed - turtle mode (24" / 20") - (Option high speed) Max speed - rabbit mode (24" / 20") - (Option high speed)	405/70-20 16PR TM R4 10 / 8,5 31 /26,5 10 / 8,5 40 / 35
Optional Tyres	
405/70-20 16PR TM R4 MICHELIN 400/80-24 162A8 IND TL POWER CL 400/80-24 / 20PR TM R4 DUNLOP 405/70R24 168A2 152J MPT SPT9 MICHELIN 400/70R24 152A8/152B IND TL XMCL DUNLOP 405/70R20 168A2 152J MPT SPT9 MICHELIN 400/70R24 152A8/152B IND TL XMCL MICHELIN 400/70R20 149A8/149B IND TL BIBLOAD - ALLIANCE 400/70-R20 149A8 ALLIANCE 405/70-R24 152A8	
Brakes Engine Braking	Hydrostatic

Engine Braking Parking and Emergency brake Service Brake Hydrostatic Passive brake Oil immersed discs



Telescopics Specifications

Steering	
Steering Pump Steering Mode	Hydrostatic with electronic regulation 2 wheel steering / 4 wheel steering / Crab-steering
Fluid Capacities	
Axles front/rear Gear box Cooling system with heater Engine oil with filter Fuel tank Hydraulic tank Hydraulic system	6,0/6,0 0.70 L 15.00 L 8.50 L 115.00 L 47.00 L 87.00 L
Fluid Specifications	
Coolant Engine Oil	Ethylen Glycol Mix 50:56 "20°C to 50°C : SAE40W 5°C to 38°C : SAE30W -30°C to 35°C : SAE10W-30 -15°C to 45°c : SAE15W-40 -40°C to 30°C : SAE5W-30 -10°C to 20°C : SAE20W-20 -20°C to 3°C : SAE10W"
Fuel Brake Fluid	Diesel or fuel
Hydraulic Fluid	None. Brakes use hydraulic system pressure MS68
Transmission Oil	ELF SF3 / TOTAL DYNATRANS FR
Grease for hinges and boom gliders	TOTAL MULTIS EP2
Controls	
Engine Starting Front auxiliary	Foot accelerator pedal Key-type starter switch and shutdown. Variable thumbwheel on joystick
Boom raising / lowering	Joystick electronic
Boom exension /retraction Service brake	Variable thumbwheel on joystick Pedal-activated wet multi-disk on front axle
Secondary brake	Passive brake
Parking brake	Passive brake
Steering	Proportional hydraulic steering via a conventional steering
Speed range and Forward/reverse drive	wheel Switch for hydrostatic motor and switch on joystick or lever for FNR
Steering modes	Button and screen for selection
Auxiliary pressure release	Bobcat Coupler
Eco mode SHS mode	Eco mode switch SHS mode switch
Instruments	

Instruments



Telescopics Specifications

- Gauges
 - Engine RPM
 - Total operating hours
 - Job hours
 - Boom angle
 - Vehicle speed
 - Fuel gauge
 - Engine coolant temperature gauge
- Indicators
 - · Front and rear wheel alignment status on screen
 - Headlight full beam
 - Headlight low beam
 - Position lights
 - Left and right turn
 - Trailer turn
 - Parking brake
 - Longitudinal stability level
 - Windscreen wipers
 - Work lights
 - Flashing warning light
 - Hazard warning lights
 - Gear Speed choice
 - Hydraulic function lock
 - Rear fog lights
 - Heater fan
 - Hydraulic fluid over-temperature
 - Engine coolant over-temperature
 - Low oil pressure
 - Battery not charging
 - Longitudinal stability alarm

Serviceability

Serviceability

- · Access through the side engine cover and access panel:
 - Air cleaner
 - Fuel filter
 - Engine oil filter
 - Engine oil dipstick
 - Starter
 - Alternator
- Access within the cab:
 - Glass washer fluid
 - $\circ~$ Fuses, diodes and relays
 - $\circ~$ ISL control box


Environmental

Operator noise level (LpA) (EN 12053) Whole body vibration (EN 13059) 78 dB(A) 1.70 ms⁻²



Telescopics Specifications

Dimensions



- (R*) External turning radius with 24" tyres (with forks spaced 1040 mm ext.)
- (G) Carriage rotation angle

B3G7 11001 — B3G7 99999 •

4820.0 mm


136.0°



Telescopics Specifications

TL26-60/TL30-60 100 High Cab IIIA R-Series Telescopic Handler

Load Charts




B3G7 11001 — B3G7 99999 • Specifications are subject to change without notice - Pictures of Bobcat units may show other than standard equipment



Telescopics Specifications

Load Charts





Telescopics Specifications

Performance

renonnance	
Tilt Breakout force	4600 daN
Drawbar pull (20" tyres)	4900 daN
Drawbar pull (24" tyres)	4100 daN
Max. gradeability (20" tyres)	24.0°
Max. gradeability (24" tyres)	24.0°
Max. gradeability with rated load (20" tyres)	24.0°
Max. gradeability with rated load (24" tyres)	24.0°
Rated capacity	3000 kg
Capacity (at max. height on tyres)	2500 kg
Capacity at max. reach (20" tyres)	1250 kg
Capacity at max. reach (24" tyres)	1300 kg
Lifting height (20" tyres)	5800.0 mm
Lifting height (24" tyres)	5890.0 mm
Max. reach (20" tyres)	3100.0 mm
Max. reach (24" tyres)	3010.0 mm
Reach at max height on tyres (20" tyres)	420.0 mm
Reach at max height on tyres (24" tyres)	330.0 mm
Cycle times	
Boom raising	5.3 s
Boom lowering	4.0 s
Boom extension	5.0 s
Boom retraction	3.6 s
Crowding	2.5 s
Dumping	2.4 s
Weights	
weights	
Unladen weight (20" tyres)	5020 kg
Unladen operating Weight (20" tyres)	5180 kg
Unlade operating Weight on front axle (20" tyres)	2340 kg
Unladen operating Weight on rear axle (20" tyres)	2840 kg
Unladen weight (24" tyres)	5140 kg
Unladen operating Weight (24" tyres)	5300 kg
Unlade operating Weight on front axle (24" tyres)	2400 kg
Unladen operating Weight on rear axle (24" tyres)	2900 kg
Max ground Pressure on tyres-hard soil	11.0
Engine	
Make / Model	PERKINS / 1104D-44TA
Fuel	DIESEL
Cooling	WATER
Rated power (ISO 14396)	74.0 kW
Rated power (ISO 14396) Rated speed	2200.0 RPM
•	
Maximum torque at 1400 rpm	410.0 Nm
Number of cylinders	4.0
Displacement	4.40 L
Bore	105.0 mm
Stroke	127.0 mm
Lubrication	Gear pump pressure
B3G7 11001 -	– B3G7 99999 •



Telescopics Specifications

Crankshaft Ventilation Air filter Ignition	Open breathing Dry replaceable cartridge with safety element Diesel compression
Electrical	
Alternator Battery Starter	90 A 110.0 3.2 kW
Hydraulic System	
Pump type Pump capacity Relief valve pressure setting Control valve type Hydraulic filter specs Auxiliary flow front Auxiliary flow rear	Gear pump with LS valve 100.00 L/min 250.00 bar Open center with flow sharing & flow compensators technology Full flow filtration 90.00 L/min 20.00 L/min
Drive system	
Transmission Main Drive	Hydrostatic with electronic regulation Hydrostatic motor
Traction	
Standard Tyres Max speed - turtle mode (24" / 20") Max speed - rabbit mode (24" / 20") Max speed - turtle mode (24" / 20") - (Option high speed) Max speed - rabbit mode (24" / 20") - (Option high speed)	405/70-20 16PR TM R4 10 / 8,5 31 /26,5 10 / 8,5 40 / 35
Optional Tyres	
405/70-20 16PR TM R4 MICHELIN 400/80-24 162A8 IND TL POWER CL 400/80-24 / 20PR TM R4 DUNLOP 405/70R24 168A2 152J MPT SPT9 MICHELIN 400/70R24 152A8/152B IND TL XMCL DUNLOP 405/70R20 168A2 152J MPT SPT9 MICHELIN 400/70R24 152A8/152B IND TL XMCL MICHELIN 400/70R20 149A8/149B IND TL BIBLOAD - ALLIANCE 400/70-R20 149A8 ALLIANCE 405/70-R24 152A8 Brakes	
Engine Braking	Hydrostatic

Engine Braking Parking and Emergency brake Service Brake Hydrostatic Passive brake Oil immersed discs



Telescopics Specifications

Steering Mode 2 wheel steering / 4 wheel steering / Crab-steering Fluid Capacities Axles front/rear 6,0/6,0 Gear box 0.70 L Cooling system with heater 15.00 L angine oil with filter 8.50 L "uel tank 115.00 L Hydraulic tank 47.00 L Hydraulic system 87.00 L Fluid Specifications 2 Wheel steering / 6 wheel steering / Crab-steering Coolant Ethylen Glycol Mix 50:56 Engine Oil "20°C to 50°C : SAE10W *30°C to 38°C : SAE30W -30°C to 35°C : SAE10W *30°C to 35°C : SAE10W	Steering	
Avles front/rear 6,0/6,0 Gear box 0.70 L Cooling system with heater 15.00 L Engine oil with filter 8.50 L 'uel tank 115.00 L Hydraulic system 87.00 L Hydraulic system 87.00 L Fluid Specifications 20°C to 50°C : SAE40W 5°C to 38°C : SAE30W -30°C to 33°C : SAE10W-30 -15°C to 45°C : SAE15W-40 -40°C to 30°C : SAE40W 5°C to 53°C : SAE15W-40 -40°C to 30°C : SAE40W 5°C to 20°C : SAE20W -20 -20°C to 3°C : SAE40W 5°C to 20°C : SAE20W -20 -20°C to 3°C : SAE40W 5°C to 20°C : SAE20W-20 -20°C to 3°C : SAE40W Fuel "20°C to 50°C : SAE40W 5°C to 20°C : SAE20W -20 -20°C to 3°C : SAE40W 5°C to 20°C : SAE20W -20 -20°C to 3°C : SAE40W* Fuel Disesl or fuel Brake Fluid None. Brakes use hydraulic system pressure Hydraulic Fluid None. Brakes use hydraulic system pressure Transmission Oil ELF SF3 / TOTAL DYNATRANS FR Grease for hinges and boom gliders TOTAL MULTIS EP2 Controls Poot accelerator pedal Starting Key-type starter switch and shutdown. 'ront auxiliary Variable thumbwheel on joystick 3com raising / lowering Joystick electronic Starting Pedal-activated wet multi-disk on front axle Sec	Steering Pump Steering Mode	
Gear box 0.70 L Cooling system with heater 15.00 L Engine oil with filter 8.50 L Fuel tank 115.00 L tydraulic tank 47.00 L tydraulic system 87.00 L Fluid Specifications Coolant Ethylen Glycol Mix 50:56 Engine Oil "20°C to 50°C : SAE40W 5°C to 38°C : SAE30W -30°C to 35°C : SAE10W-30 -15°C to 45°c : SAE15W-40 -40°C to 30°C : SAE40W 5°C to 33°C : SAE40W 5°C to 53°C : SAE40W 5°C to 33°C : SAE40	Fluid Capacities	
Cooling system with heater 15.00 L Engine oil with filter 8.50 L Vel tank 47.00 L Hydraulic system 87.00 L Hydraulic system 87.00 L Fluid Specifications 20°C to 50°C : SAE40W 5°C to 38°C : SAE30W -30°C to 35°C : SAE50W -30°C to 35°C : SAE10W -30°C to 35°C : SAE10W -30°C to 30°C : SAE5W-30 -15°C to 45° c : SAE15W-40 -40°C to 3°C : SAE10W -30°L to 3°C : SAE10W -30°L to 3°C : SAE10W -30°L to 20°C : SAE10W -20 -20°C to 3°C : SAE10W -30°L to 20°C : SAE10W -20 -20°C to 3°C : SAE10W -30°L to 20°C : SAE10W -20 -20°C to 3°C : SAE10W -30°L to 20°C : SAE10W -20 -20°C to 3°C : SAE10W -30°L to 20°C : SAE10W -20 -20°C to 3°C : SAE10W -30°L to 20°C : SAE10W -30°L to 30°C : SAE10W -30°L to 20°C : SAE10W -30°L to 20°L to 20°L to 20°L to 20°L to 20°L	Axles front/rear	
Engine of with filter 8.50 L Tuel tank 115.00 L Hydraulic tank 47.00 L Fluid Specifications Coolant Ethylen Glycol Mix 50:56 Engine Oil "20°C to 50°C : SAE40W 5°C to 38°C : SAE30W -30°C to 35°C : SAE10W-30 -15°C to 45°c : SAE15W-40 -40°C to 35°C : SAE10W-30 -15°C to 45°c : SAE20W-20 -20°C to 3°C : SAE10W-30 -15°C to 20°C : SAE20W-20 -20°C to 3°C : SAE10W" Fuel Srake Fluid None. Brakes use hydraulic system pressure Hydraulic Fluid None. Brakes use hydraulic system pressure Hydraulic Fluid None. Brakes use hydraulic system pressure To TAL MULTIS EP2 Controls Engine Foot accelerator pedal Starting Key-type starter switch and shutdown. Front auxiliary Variable thumbwheel on joystick Service brake Pedal-activated wet multi-disk on front axle Secondary brake Passive brake Passive brake Passive brake Passive brake Passive brake Speed range and Forward/reverse drive Steering modes Auxiliary pressure release Eco mode Eco mode switch		
Fuel tank 115.00 L tydraulic tank 47.00 L tydraulic system 87.00 L Fluid Specifications Coolant Ethylen Glycol Mix 50:56 Engine Oil "20°C to 50°C : SAE40W 5°C to 38°C : SAE30W -30°C to 38°C : SAE10W-30 -15°C to 45°c : SAE10W-40 -40°C to 30°C : SAE5W-30 -10°C to 20°C : SAE20W-20 -20°C to 3°C : SAE5W-30 -10°C to 20°C : SAE20W-20 -20°C to 3°C : SAE10W" Fuel Diesel or fuel Brake Fluid None, Brakes use hydraulic system pressure tydraulic Fluid MS68 Transmission Oil ELF SF3 / TOTAL DYNATRANS FR Grease for hinges and boom gliders TOTAL MULTIS EP2 Controls Starting Front auxiliary Variable thumbwheel on joystick Soom exension /retraction Variable thumbwheel on joystick Service brake Pedal-activated wet multi-disk on front axle Secondary brake Passive brake Steering Proportional hydraulic steering via a conventional steering via a conventional steering viewed for FNR Steering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler Eco mode Eco mode switch		
Hydraulic tank 47.00 L Hydraulic system 87.00 L Fluid Specifications Ethylen Glycol Mix 50:56 Engine Oil "20°C to 50°C : SAE40W 5°C to 38°C : SAE30W -30°C to 38°C : SAE15W-40 -40°C to 30°C : SAE40W-30 -15°C to 45°C : SAE15W-40 -40°C to 30°C : SAE10W" Fuel Dissel or fuel Brake Fluid None. Brakes use hydraulic system pressure Hydraulic Fluid MS68 Transmission Oil ELF SF3 / TOTAL DYNATRANS FR Grease for hinges and boom gliders TOTAL MULTIS EP2 Controls Starting Engine Foot accelerator pedal Starting Key-type starter switch and shutdown. Soom raising / lowering Joystick electronic Boom exension /retraction Variable thumbwheel on joystick Service brake Pedal-activated wet multi-disk on front axle Secondary brake Passive brake Parke Proportional hydraulic steering via a conventional steering wheel Speed range and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR Steering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler		
hydraulic system 87.00 L Fluid Specifications Ethylen Glycol Mix 50:56 Engine Oil "20°C to 50°C : SAE40W 5°C to 38°C : SAE30W -30°C to 35°C : SAE10W-30 -15°C to 45°c : SAE15W-40 -40°C to 35°C : SAE10W" Fuel Dissel or fuel Brake Fluid None. Brakes use hydraulic system pressure Hydraulic Fluid MS68 Transmission Oil ELF SF3 / TOTAL DYNATRANS FR Grease for hinges and boom gliders TOTAL MULTIS EP2 Controls Soom raising / lowering Soom raising / lowering Joystick electronic Soom exension /retraction Variable thumbwheel on joystick Service brake Pedal-activated wet multi-disk on front axle Secondary brake Passive brake Parking brake Passive brake Speed range and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR Steering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler Soom carge and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR		
Coolant Ethylen Glycol Mix 50:56 Engine Oil "20"C to 50"C : SAE40W 5"C to 38"C : SAE30W -30"C to 30"C : SAE5W-30 -15"C to 45"c : SAE15W-40 -40"C to 30"C : SAE5W-30 -15"C to 45"c : SAE15W-40 -40"C to 30"C : SAE5W-30 -10"C to 20"C : SAE20W-20 -20"C to 3"C : SAE10W" Fuel Diesel or fuel Brake Fluid None. Brakes use hydraulic system pressure Hydraulic Fluid MS68 Transmission Oil ELF SF3 / TOTAL DYNATRANS FR Grease for hinges and boom gliders TOTAL MULTIS EP2 Controls Starting Foot accelerator pedal Key-type starter switch and shutdown. Front auxiliary Variable thumbwheel on joystick Boom raising / lowering Joystick electronic Boom raising / lowering Joystick electronic Service brake Pedal-activated wet multi-disk on front axle Secondary brake Passive brake Passive brake Passive brake Steering Proportional hydraulic steering via a conventional steering wheel Speed range and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR Steering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler Soo mode	Hydraulic system	
Engine Oil "20°C to 50°C : SAE40W 5°C to 38°C : SAE30W -30°C to 35°C : SAE10W-30 -15°C to 45°c : SAE15W-40 -40°C to 30°C : SAE5W-30 -10°C to 20°C : SAE5W-40 -40°C to 3°C : SAE10W" Fuel Diesel or fuel Brake Fluid None. Brakes use hydraulic system pressure Hydraulic Fluid MS68 Transmission Oil ELF SF3 / TOTAL DYNATRANS FR Grease for hinges and boom gliders TOTAL MULTIS EP2 Controls Engine Engine Foot accelerator pedal Starting Key-type starter switch and shutdown. Front auxiliary Variable thumbwheel on joystick Boom raising / lowering Joystick electronic Boom exension /retraction Variable thumbwheel on joystick Service brake Pedal-activated wet multi-disk on front axle Parking brake Passive brake Passive brake Passive brake Steering Proportional hydraulic steering via a conventional steering wheel Speed range and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR Beering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler Eco mode Eco mode switch	Fluid Specifications	
Brake FluidNone. Brakes use hydraulic system pressureHydraulic FluidMS68Transmission OilELF SF3 / TOTAL DYNATRANS FRGrease for hinges and boom glidersTOTAL MULTIS EP2ControlsEngineStartingFoot accelerator pedalStartingKey-type starter switch and shutdown.Front auxiliaryVariable thumbwheel on joystickBoom raising / loweringJoystick electronicBoom raising / loweringJoystick electronicBoom raising / loweringPedal-activated wet multi-disk on front axleService brakePassive brakeParking brakePassive brakeParking brakePassive brakeSteeringProportional hydraulic steering via a conventional steering wheelSteering modesButton and screen for selectionAuxiliary pressure releaseBobcat CouplerEco modeEco mode switch	Coolant Engine Oil	"20°C to 50°C : SAE40W 5°C to 38°C : SAE30W -30°C to 35°C : SAE10W-30 -15°C to 45°c : SAE15W-40 -40°C to 30°C : SAE5W-30 -10°C to 20°C : SAE20W-20 -20°C to
Hydraulic Fluid MS68 Transmission Oil ELF SF3 / TOTAL DYNATRANS FR Grease for hinges and boom gliders TOTAL MULTIS EP2 Controls Foot accelerator pedal Starting Key-type starter switch and shutdown. Front auxiliary Variable thumbwheel on joystick Boom raising / lowering Joystick electronic Boom exension /retraction Variable thumbwheel on joystick Service brake Pedal-activated wet multi-disk on front axle Secondary brake Passive brake Parking brake Passive brake Steering Proportional hydraulic steering via a conventional steering wheel Speed range and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR Steering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler Eco mode Eco mode switch	Fuel	Diesel or fuel
Transmission OilELF SF3 / TOTAL DYNATRANS FR TOTAL MULTIS EP2Grease for hinges and boom glidersTOTAL MULTIS EP2ControlsFoot accelerator pedal Key-type starter switch and shutdown.EngineFoot accelerator pedal Key-type starter switch and shutdown.Stornd auxiliaryVariable thumbwheel on joystick Joystick electronicBoom raising / loweringJoystick electronic Variable thumbwheel on joystickBoom exension /retractionVariable thumbwheel on joystick Service brakeBecondary brakePedal-activated wet multi-disk on front axle Passive brakeParking brakePassive brakeBopeed range and Forward/reverse driveSwitch for hydrostatic motor and switch on joystick or leve for FNRSteering modesButton and screen for selection Bobcat Coupler Eco mode	Brake Fluid	
Grease for hinges and boom gliders TOTAL MULTIS EP2 Controls Foot accelerator pedal Engine Foot accelerator pedal Starting Key-type starter switch and shutdown. Front auxiliary Variable thumbwheel on joystick Boom raising / lowering Joystick electronic Boom exension /retraction Variable thumbwheel on joystick Service brake Pedal-activated wet multi-disk on front axle Secondary brake Passive brake Parking brake Passive brake Steering Proportional hydraulic steering via a conventional steering wheel Speed range and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR Steering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler Eco mode Eco mode switch		
Controls Engine Foot accelerator pedal Starting Key-type starter switch and shutdown. Front auxiliary Variable thumbwheel on joystick Boom raising / lowering Joystick electronic Boom exension /retraction Variable thumbwheel on joystick Service brake Pedal-activated wet multi-disk on front axle Secondary brake Passive brake Parking brake Passive brake Steering Proportional hydraulic steering via a conventional steering wheel Speed range and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR Steering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler Eco mode Eco mode switch		
EngineFoot accelerator pedalStartingKey-type starter switch and shutdown.Front auxiliaryVariable thumbwheel on joystickBoom raising / loweringJoystick electronicBoom exension /retractionVariable thumbwheel on joystickService brakePedal-activated wet multi-disk on front axleSecondary brakePassive brakeParking brakePassive brakeSteeringProportional hydraulic steering via a conventional steering wheelSpeed range and Forward/reverse driveSwitch for hydrostatic motor and switch on joystick or leve for FNRSteering modesButton and screen for selectionAuxiliary pressure releaseBobcat Coupler Eco mode		TOTAL MULTIS EP2
StartingKey-type starter switch and shutdown.Front auxiliaryVariable thumbwheel on joystickBoom raising / loweringJoystick electronicBoom exension /retractionVariable thumbwheel on joystickBervice brakePedal-activated wet multi-disk on front axleSecondary brakePassive brakeParking brakePassive brakeSteeringProportional hydraulic steering via a conventional steering wheelSpeed range and Forward/reverse driveSwitch for hydrostatic motor and switch on joystick or leve for FNRSteering modesButton and screen for selectionAuxiliary pressure releaseBobcat Coupler Eco mode		
Front auxiliaryVariable thumbwheel on joystickBoom raising / loweringJoystick electronicBoom exension /retractionVariable thumbwheel on joystickBervice brakePedal-activated wet multi-disk on front axleBecondary brakePassive brakeParking brakePassive brakeParking brakePassive brakeBeed range and Forward/reverse driveSwitch for hydrostatic motor and switch on joystick or leve for FNRSteering modesButton and screen for selectionAuxiliary pressure releaseBobcat Coupler Eco modeEco modeEco mode switch		
Boom raising / loweringJoystick electronicBoom exension /retractionVariable thumbwheel on joystickBervice brakePedal-activated wet multi-disk on front axleBecondary brakePassive brakeParking brakePassive brakeParking brakePassive brakeBeeeringProportional hydraulic steering via a conventional steering wheelSpeed range and Forward/reverse driveSwitch for hydrostatic motor and switch on joystick or leve for FNRSteering modesButton and screen for selectionAuxiliary pressure releaseBobcat Coupler Eco modeEco modeEco mode switch	-	
Boom exension /retractionVariable thumbwheel on joystickService brakePedal-activated wet multi-disk on front axleSecondary brakePassive brakeParking brakePassive brakeParking brakeProportional hydraulic steering via a conventional steering wheelSpeed range and Forward/reverse driveSwitch for hydrostatic motor and switch on joystick or leve for FNRSteering modesButton and screen for selectionAuxiliary pressure releaseBobcat Coupler Eco mode		
Service brakePedal-activated wet multi-disk on front axleSecondary brakePassive brakeParking brakePassive brakeParking brakeProportional hydraulic steering via a conventional steering wheelSpeed range and Forward/reverse driveSwitch for hydrostatic motor and switch on joystick or leve for FNRSteering modesButton and screen for selectionAuxiliary pressure releaseBobcat Coupler Eco mode		
Parking brake Passive brake Steering Proportional hydraulic steering via a conventional steering wheel Speed range and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR Steering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler Eco mode Eco mode switch		
Steering Proportional hydraulic steering via a conventional steering wheel Speed range and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR Steering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler Eco mode Eco mode switch	Secondary brake	Passive brake
Speed range and Forward/reverse drive wheel Speed range and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR Steering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler Eco mode Eco mode switch	Parking brake	
Speed range and Forward/reverse drive Switch for hydrostatic motor and switch on joystick or leve for FNR Steering modes Button and screen for selection Auxiliary pressure release Bobcat Coupler Eco mode Eco mode switch	Steering	
Auxiliary pressure releaseBobcat CouplerEco modeEco mode switch	Speed range and Forward/reverse drive	Switch for hydrostatic motor and switch on joystick or leve
Eco mode Switch	Steering modes	
SHS mode SHS mode switch		
	SHS mode Instruments	SHS mode switch

Instruments



Telescopics Specifications

Gauges

- Engine RPM
- Total operating hours
- Job hours
- Boom angle
- Vehicle speed
- Fuel gauge
- Engine coolant temperature gauge
- Indicators
 - · Front and rear wheel alignment status on screen
 - Headlight full beam
 - Headlight low beam
 - Position lights
 - Left and right turn
 - Trailer turn
 - Parking brake
 - Longitudinal stability level
 - Windscreen wipers
 - Work lights
 - Flashing warning light
 - Hazard warning lights
 - Gear Speed choice
 - Hydraulic function lock
 - Rear fog lights
 - Heater fan
 - Hydraulic fluid over-temperature
 - Engine coolant over-temperature
 - Low oil pressure
 - Battery not charging
 - Longitudinal stability alarm

Serviceability

Serviceability

- · Access through the side engine cover and access panel:
 - Air cleaner
 - Fuel filter
 - Engine oil filter
 - Engine oil dipstick
 - Starter
 - Alternator
- Access within the cab:
 - Glass washer fluid
 - $\circ~$ Fuses, diodes and relays
 - $\circ~$ ISL control box

Environmental

Operator noise level (LpA) (EN 12053) Whole body vibration (EN 13059) 78 dB(A) 1.70 ms⁻²